HINGE DOOR: INSTALLATION INSTRUCTION

ALUMINUM FRAME HINGE DOOR RPS

Version 1.1 (2017-03-30)

2.30.2.c

easy medium difficult

Installation

Subject to technical changes.



CONTENT AND TOOLS

CONTENT:	Content and tools	page	02
	Product information	page	03
	Accessories	page	05
	Detail drawings	page	06
	Installation instruction	page	07
	Detail drawings Release device application	page	09

TOOLS:

(without claim of completeness)

- Allen key set
- Screwdriver set
- Water level

(i)

VERSION INFORMATION:

Version 1.1: System information adapted

PRODUCT INFORMATION

GENERAL INFORMATION: Preparation

- This manual is part of the product and describes the safe and proper installation of the system. Please read the instructions carefully before installation
- Please note that the assembly should only be done by qualified and trained staff in strict compliance with all details indicated in this document. Improper installation in variation from manufacturer's specification may cause defects and danger, thus endangering the safe fixing of the product as well as the safety of the prospective user. The liability of the manufacturer shall be excluded in case of defects and consequential damages resulting from incorrect assembly of this product.
- Please check the completeness of the delivered parts and check carefully if any transport damages are visible.
- If any parts are damaged or lost, please immediately contact the responsible supplier.
- It is assumed that you have exactly identified all cutting dimensions according to the measurement instruction for **raumplus** products.

SYMBOLE:

Symbol Importance

Risk or danger!



Advice and information



Additional information / other documents



Directional data / direction of movement



"yes" and "right"



"no" and "wrong"



Follow the order

Symbol Importance



During the installation do not use a striking tool



No leverage tool for disassembly of fittings



Be aware of the risk of entrapment.



do not enter!

SYSTEM:

System Information: RPS

- max. weight of element
- min./max. door height
- min./max. door width
- = 20 kg
- = 300 mm / 2500 mm
- = 300 mm / 620 mm

PRODUCT INFORMATION

GENERAL INFORMATION: Product safety

The system complies with the prior of the art and the authorized safety rules at the time of delivery.

USE:

Intended use

- The prerequisite for the intended use of our products is the professional installation according to our installation instruction. Sufficient fittings must be available and durably installed to all relevant places.

 The function of the fittings must not be hindered or altered during installation.
- Special solutions are only possible in consultation with raumplus.


Incorrect use


- Risk or danger may occur in the following cases:
- the door system has improperly been installed or maintained
- the safety and installation instructions have not been followed.
- after improper installation or inadequate fixing (e.g. to parts of buildings)
- the maximum weight of the doors has been exceeded.
- improper shock and case loads or other additional loads on the fittings have occured
- the fittings have been used outside.
- body parts or objects got into the closing edges or door runnings during use of the door wing.
- the door system is not used as intended.


Structural modifications


Structural modifications that are not offered as an accessory from **raumplus** may only be attached or installed with permission of **raumplus** GmbH!


ACCESSORIES



















7_ 10.52.025

- **1**_ Frame profile **22,5** mm, RPS
- 2_ Frame profile 29 mm, RPS

3 _ Hinge bo	ottom right/top left nickel fir	n./ p2o	(10.52.021)
Hinge bo	ottom right / top left titanium	fin./ p2o	(10.52.023)
Hinge bo	ottom right / top left nickel fir	./soft close	(10.52.031)
Hinge bo	ottom right / top leftn titaniur	n fin./soft close	(10.52.033)


- 4_ Hinge bottom left / top right nickel fin./ p2o (10.52.020)
 Hinge bottom left / top right titanium fin./ p2o (10.52.022)
 Hinge bottom left / top right nickel fin./ soft close (10.52.030)
 Hinge bottom left / top right titanium fin./soft close (10.52.032)
- **5**_ Adapter plate set RPS

- **6**_ Magnetic push p2o grey
- 7_ Locking plate self adhesive p2o


8 _ Handle rectangular	(10.01.91x)
Concave handle one-sided	(10.01.92x)
Concave handle both sides	(10.01.93x)

DETAIL DRAWING

CORPUS VARIANTS









2_ Adapter variant

INSTALLATION INSTRUCTION

INSTALLATION OF DOOR




1_ Insert the hinges in the corpus




2_ Insert the door

INSTALLATION INSTRUCTION


ADJUST THE DOOR



1_ Side adjustment +**2** mm to -**2** mm



2_ Depth adjustment +2 mm to -0,5 mm




3_ Height adjustment +1,5 mm to -1,5 mm

DETAIL DRAWING

MAGNETIC PUSH P20 GREY

Drill a hole \emptyset 10 mm and min. 40 mm depth in the top, the side or the base panel of the cabinet. Insert the release device into the hole..



For the position of the hole note the following instructions:
Aluminium frame hinge door RPS Planning

1_ Application of the release device


Apply the retaining catch to the magnetic release device. Remove the protective strip from the adhesive. Close the door. In this way the retaining catch is positioned on the door. Reopen the door and apply a firm pressure to the retaining catch to ensure a correct installation.

ATTENTION:

For a correct application and to ensure optimal endurance, we suggest these guidelines are followed:

- 1 clean and degrease the door surface where the retaining catch is to be installed;
- 2 remove the protective strip from the adhesive;
- 3 place the retaining catch in position, in a place that is at room temperature $\geq 10^{\circ}$ and apply a firm pressure for 10-15 seconds.


After few seconds from the installation the retaining catch is suitable for the use. After 24h the max. hold is attained.




4_ Retaining catch with adhesive strip

DETAIL DRAWING

PUSH TO OPEN / HANDLE



1_ Installation release device for push to open hinges



2_ Sticking the handle